DMX CHANNEL'S FUNCTIONS AND THEIR VALUES (26 TO 199 DMX CHANNELS) - V130

Mode/ Channels				Function		Value	Default Value
Ba	Std	Ext Ring	Ext Pixel				
1	1	1	1	**PAN Movement 8bit**		0-255	128
2	2	2	2	**Pan Fine 16bit**: Fine control of Pan movement		0-255	0
3	3	3	3	**TILT Movement 8bit**		0-255	128
4	4	4	4	**Tilt Fine 16bit**: Fine control of Tilt movement		0-255	0
5	5	5	5	**Speed Fan/Tilt Movement**	Max to min speed	0-225	0
					Blackout by movement	226-235	
					No Feature	236-245	
6	6	6	6	**Reserved**			0
7	7	7	7	**Reserved**			
8	8	8	8	**Red LED-All Arrays / Background Colour When Chase ON**: Red (0-Black, 255-100% Red)		0-255	255
9	9	9	9	**Red Fine LED-All Arrays / Background Colour When Chase ON**: Red fine (0-Black, 255-100% Red)		0-255	255
10	10	10	10	**Green LED-All Arrays / Background Colour When Chase ON**: Green (0-Black, 255-100% Green)		0-255	255
11	11	11	11	**Green Fine LED-All Arrays / Background Colour When Chase ON**: Green (0-Black, 255-100% Green)		0-255	255
12	12	12	12	**Blue LED-All Arrays / Background Colour When Chase ON**: Blue (0-Black, 255-100% Blue)		0-255	255
13	13	13	13	**Blue Fine LED-All Arrays / Background Colour When Chase ON**: Blue fine (0-Black, 255-100% Blue)		0-255	255
14	14	14	14	**White LED-All Arrays / Background Colour When Chase ON**: White (0-Black, 255-100% White)		0-255	255
15	15	15	15	**White Fine LED-All Arrays / Background Colour When Chase ON**: White fine (0-Black, 255-100% White)		0-255	255
16	16	16	16	**Shutter, Strobe**	LED turn off	0-31	32
					LED turn on	32-63	
					Strobe effect slow to fast	64-95	
					LED turn on	96-127	
					Pulse-effect in sequences	128-159	
					LED turn on	160-191	
					Random strobe effect slow to fast	192-223	
					LED turn on	224-255	
17	17	17	17	**Dimmer Intensity**: Intensity 0 to 100%		0-255	0
18	18	18	18	**Dimmer Intensity Fine**		0-255	0
19	19	19	19	**Linear CTO From 8000 To 2700 K**	No function	0-21	0
					8000 K	22-42	
					7500 K	43-63	
					7000 K	64-84	
					6500 K	85-105	
					6000 K	106-126	
					5500 K	127-147	
					5000 K	148-168	
					4500 K	169-189	
					4000 K	190-210	

Mode/ Channels				Function		Value	Default Value
19	19	19	19	**Linear CTO From 8000 To 2700 K**	3500 K	211-231	
					2700 K	232-255	
20	20	20	20	**Colour Preset**	No function	0-2	0
					See Appendix	3-205	
					No function	206-255	
21	21	21	21	**Colour Preset / RGBW Cross Fade**	Output controlled by RGBL values	0	0
					Cross fade between RGBL settings and Colour preset channel	1-254	
					Output controlled by colour preset values	255	
22	22	22	22	**Between Colour Preset Cross Fade**	No fade	0-4	0
					Cross fade between 2 colour presets from 100 ms to 5 sec	4-255	
23	23	23	23	**Zoom:** From small to big		0-255	128
24	24	24	24	**Zoom Fine**		0-255	0
25	25	25	25	**Reserved**			0
26	26	26	26	**Reset, Internal Programs**	unused	0-4	0
					Display Off	5-9	
					Display On	10-14	
					Display Invert Off	15-19	
					Display Invert On	20-24	
					Auto fan control mode	25-26	
					Stage fan control mode	27-28	
					Silence fan control mode	29-30	
					Super Silence fan control mode	31-32	
					Constant Fans Off	33-34	
					Constant Fans On	35-36	
					unused	37-44	
					Square Law	45-49	
					Linear	50-54	
					1.2K	55-57	
					2.4K	58-60	
					16K	61-63	
					25K	64-69	
					Tungsten lamp simulation 500 W	70-71	
					Tungsten lamp simulation 1000 W	72-73	
					Tungsten lamp simulation 2500 W	74-75	
					Tungsten lamp simulation 5000 W	76-77	
					Tungsten lamp simulation off	78-79	
					All motor reset	80-84	
					P/T motor reset	85-87	
					Zoom motor reset	88-90	
					Pan Degree 540°	91-93	
					Pan Degree 630°	94-96	

Mode/ Channels			Function		Value	Default Value
26	26	26	Reset, Internal Programs	Pan/Tilt Spd Fast	97-99	0
				Pan/Tilt Spd Medium	100-102	
				Pan/Tilt Spd Slow	103-105	
				Reserved	106-255	
27	27	27	Main LED Chase Pattern	Chase OFF	0-9	0
				Chase 1	10-14	
				Chase 2	15-19	
				Reserved	45-255	
28	28	28	Main LED Chase Speed	Fast to Slow Backward	0-125	0
				Stop (Speed=0)	126-130	
				Slow to Fast Forward	131-255	
29	29	29	**Main LED Chase Fade**		0-255	0
30	30	30	**Main LED Chase Size**: Chase category		0-255	0
31	31	31	**Red Chase Colour**: Red (0-Black, 255-100% Red)		0-255	255
32	32	32	**Green Chase Colour**: Green (0-Black, 255-100% Green)		0-255	255
33	33	33	**Blue Chase Colour**: Blue (0-Black, 255-100% Blue)		0-255	255
34	34	34	**White Chase Colour**: White (0-Black, 255-100% White)		0-255	255
35	35	35	**Dimmer Chase**: Intensity (0-Black , 255-100%)		0-255	0
36	36	36	**Dimmer Background Chase Inverted Disabled When Chase OFF**: Intensity (0-100% , 255-0%)		0-255	0
37	37	37	Chase, Strobe:	LED turn off	0-31	32
				LED turn on	32-63	
				Strobe effect slow to fast	64-95	
				LED turn on	96-127	
				Pulse-effect in sequences	128-159	
				LED turn on	160-191	
				Random strobe effect slow to fast	192-223	
				LED turn on	224-255	
		38 | 50	**Reserved**		0-255	
	38	51	**Cross Fade to PIXEL Mode**: From RGBW control to PIXEL control		0-255	128
	39		**Red LED-Ring 1**: Red (0-Black, 255-100% Red)		0-255	255
	40		**Green LED-Ring 1**: Green (0-Black, 255-100% Green)		0-255	255
	41		**Blue LED-Ring 1**: Blue (0-Black, 255-100% Blue)		0-255	255
	42		**White LED-Ring 1**: White (0-Black, 255-100% White)		0-255	255
	43		**Red LED-Ring 2**: Red (0-Black, 255-100% Red)		0-255	255
	44		**Green LED-Ring 2**: Green (0-Black, 255-100% Green)		0-255	255
	45		**Blue LED-Ring 2**: Blue (0-Black, 255-100% Blue)		0-255	255
	46		**White LED-Ring 2**: White (0-Black, 255-100% White)		0-255	255
	47		**Red LED-Ring 3**: Red (0-Black, 255-100% Red)		0-255	255
	48		**Green LED-Ring 3**: Green (0-Black, 255-100% Green)		0-255	255
	49		**Blue LED-Ring 3**: Blue (0-Black, 255-100% Blue)		0-255	255
	50		**White LED-Ring 3**: White (0-Black, 255-100% White)		0-255	255

Mode/ Channels			Function	106-255	Default Value
	51		**Red LED-Ring 4**: Red (0-Black, 255-100% Red)	0-255	255
	52		**Green LED-Ring 4**: Green (0-Black, 255-100% Green)	0-255	255
	53		**Blue LED-Ring 4**: Blue (0-Black, 255-100% Blue)	0-255	255
	54		**White LED-Ring 4**: White (0-Black, 255-100% White)	0-255	255
		52	**Red LED-Array 1**: Red (0-Black, 255-100% Red)	0-255	255
		53	**Green LED-Array 1**: Green (0-Black, 255-100% Green)	0-255	255
		54	**Blue LED-Array 1**: Blue (0-Black, 255-100% Blue)	0-255	255
		55	**White LED-Array 1**: White (0-Black, 255-100% White)	0-255	255
		56	**Red LED-Array 2**: Red (0-Black, 255-100% Red)	0-255	255
		57	**Green LED-Array 2**: Green (0-Black, 255-100% Green)	0-255	255
		58	**Blue LED-Array 2**: Blue (0-Black, 255-100% Blue)	0-255	255
		59	**White LED-Array 2**: White (0-Black, 255-100% White)	0-255	255
...					
		196	**Red LED-Array 37**: Red (0-Black, 255-100% Red)	0-255	255
		197	**Green LED-Array 37**: Green (0-Black, 255-100% Green)	0-255	255
		198	**Blue LED-Array 37**: Blue (0-Black, 255-100% Blue)	0-255	255
		199	**White LED-Array 37**: White (0-Black, 255-100% White)	0-255	255

Errors and omissions for all information given in this DMX chart are possible.
All information is subject to change without prior notice.

SCAN FOR MORE

www.ayrton.eu

AYRTON

Digital Lighting